

Instructions for Printing a DESI Label

Go To Extension on the top Navigation Bar and Click, the dropdown menu appears and choose New Extension.

A Popup Box will Appear

Enter the Extension Number you want to print.

Under Product Family go to ESI IVX (Hit E on your keypad for shortcut)

Under Model Choose your Phone, The 3 Choices are:

1. The 48-Key Feature Phone has 30 Programmable Buttons on the Right side of your phone. (Most likely the phone you have on an S Class or E Class)
2. The 24 Button Feature Phone has 12 Programmable Buttons on the Top of Your Phone. (Is the phone you have for a C Class or can be used on the S or E Class.)
3. The EKT-A has 16 Programmable Buttons on the top of your phone. (Use this if you have an ESI 20, 20+, 128 or 128+.)

Under Template keep it at NO TEMPLATE

Leave the Field Blank and do not check either of the boxes

Press OK

The Template Will Appear

Double Click on the White Area of the Top Left Button

A Text Editor Will Appear and enter the name of the button and click OK

Repeat until the labels are filled to your desire

Put the DESI Label in Your printer according to the instruction on the DESI

Click on File on your Top Navigation Bar, on the dropdown click Print DESI Labels

Your Label Should Print out properly.

To Order New DESI's

Go to our Website at www.clearchoiceinc.com

Click on Phone Systems and on the dropdown click on System Documentation

On the top of the Page Click on the link that says Order your DESI's Here to order online.